

Installation Instructions

Light Cover

www.RotoLiteInc.com



BASE & COVER WILL WORK WITH MOST COMMERCIALLY MANUFACTURED LIGHT FIXTURES

- 1 Turn off power
- 2 Remove existing fixture.
- 3 Dig a hole 16" wide x 20" long x 8" deep (be careful to retain sod to cover up hole when completed).
- 4 Place base unit in hole leaving 1" to 2" above ground
Note: The round male connector on the top of the base unit must be offset (short side) to the side closest to the tree
- 5 Pull wires through top of base unit.
- 6 Place a level across the top of the base unit to make sure it is level.
- 7 Fill in dirt, and replace grass
- 8 Install light fixture, Make sure it is aimed properly.
Note: the base unit and cover will work with most commercially manufactured light fixtures
- 9 Place hood over the lamp and secure it to the base using four tamper-proof screws.

YOU MUST BE A LICENSED ELECTRICIAN OR APPROVED CONTRACTOR TO WIRE 120 VOLT FIXTURES.

*All fixtures are assembled using UL or CE listed components

